

ERRATA

PUBLICATION: Design Guide for Square Spread Footings for Individual Columns

The following page/s supercede the versions currently shown in the CRSI *Design Guide for Square Spread Footings for Individual Columns*, and should be referenced as such. This errata applies to the 1st Edition specifically noted as the "1st Printing".

Updates and/or corrections apply to the following pages/content: **T-1 through T-30**

Concentrically Loaded Individual Square Footings (ACI 318-11) Tables

The headings for design tables, **Unfactored Soil Pressure** and **Factored Soil Pressure** incorrectly show units of "psi":

Unfactored Soil Pressure = 1,000 psi
Factored Soil Pressure = 1,400 psi

The correct units are "psf":

Unfactored Soil Pressure = 1,000 psf
Factored Soil Pressure = 1,400 psf

